




# STEP 1

Elevators with Swing Service mode activated are confusing for passengers with buttons that do not work (most floors are not accessible).

TTG touchscreens have the solution.




## STEP 2

The TTG will be programmed to only show the active floors on the graphic.

When the elevator changes to Swing, the graphic changes to show other sets of floors.

# STEP 3

Likewise, in Fire Service all floors are shown.



# Technical Stuff:

What is required for this feature?

- In the COP, we require 1 output for the TTG system to monitor and trigger graphic change when put onto Swing Service
- All other aspects of installation typical to regular TTG installation.

