

INSTALLATION GUIDE

LS-250 RESCUE STATION

WIRING DIAGRAM (TYPICAL)

